



AEM EMS 30-6100 Install to '01 IS300



Title AEM EMS 30-6100 2001 IS300 Install		
Author Cody Graham		
File C:\Users\Cody\Desktop\laem ems install.dsn	Document	
Revision 1.0	Date 7/15/2012	Sheets 1 of 1

AEM EMS 30-6100 Install to '02-'05 IS300



Notes:
 X indicates a cut wire that no longer connects - the original wire is left in place to show where it originally connected

Not all wires are listed on this diagram only those that are required for installation

Please verify for your application the author will not be held responsible for any damage that occurs due to incorrect installation or any other issues

Pin numbers are located in AEM install manual for 30-6100, and in the '02-'05 IS300 TSRM

Wiring diagram can be adapted for almost any AEM EMS

Title AEM EMS 30-6100 2002-2005 IS300 Install		
Author Cody Graham		
File	:\Users\Cody\Desktop\laem ems install 02-05.dsn	
Revision 1.0	Date 7/15/2012	Document Sheets 1 of 1